



Type II: at least 1 cubic foot per minute per square foot in the dry-clean and drying rooms. Type IV / V: exhaust at the loading door.

Original Masterbuild PE packet from Daily Code Talk on 2024 IMC 502.6. Confirm the adopted edition. Distinct from 502.12 coating (also 1 cfm/ft², but floor pickup for Class I coating) and 502.7 spray. This is not a dry-clean plant design. The code does not put a single feet-per-minute number on the Type IV/V door here — put the basis on the exhaust schedule.

☐ **Type II: 1 cfm/ft² in the dry-clean room and the drying room — floor area, not wall area.**

A 150-cfm ceiling fan over 400 square feet is not 1 cfm/ft².

☐ **Type IV / V: exhaust tied to the loading-door area, or a hood over that opening.**

A high grille over a closed machine does not sweep the door.

☐ **Discharge outdoors. Do not recirculate solvent vapor into the shop.**

Do not take makeup from a hazardous room. The name on the door is not the code path.

The fail we see first

A Type II plant with a 150-cfm ceiling fan over 400 ft². Or a Type IV/V machine with no hood at the loading door — the operator is in the vapor when the door opens.

What to send: machine type (II / IV / V if you know it), floor area of the dry-clean and drying rooms, and whether there is a hood at the loading door.

Send the comments. Not the County guideline.

Folio (does it start with 30?), process or UP number, and the comments PDF. Masterbuild will say which row is actually open.

masterbuildconsulting.com/send/

+1 (786) 398-6940 · Calendly: 30-minute scoping call

Masterbuild provides engineering services under a written scope. Not a dry-clean plant design. Confirm adopted 502.6. This is not legal advice.